



Jan 2015



COMPLETE TRIM



WE-WM-1/2VC



WE-WM-3/4VC



WE-WM-DIV

**It is strongly advised to employ a professional plumber when installing this product.**

1. The valves may be placed anywhere, depending on the home owner's preference and local plumbing code. For all valves, make note of inlets and outlets before plumbing!
2. Separate the Valves from the Trim:
  - a. For trim with set screw on the handle:
    - i. With a #2 Allen wrench, loosen the set screw and remove from the handle.
    - ii. With a Phillips-head screwdriver, remove the screw holding the handle stem.
    - iii. Proceed to (c):
  - b. For trim without set screw on handle, proceed to next step:
  - c. Unscrew the escutcheon from the valve stem.
3. Valves should be installed at or cut down to 2-1/4" of the stem exposed from the wall. At least 1/2", and no more than 1-3/4" of the all-thread should be exposed from wall.
4. Water Test.
5. Install the trim reversing the steps made in step 2. Remember to place the trim ring on the wall before the escutcheon.
6. If the handle doesn't "clock" straight, remove and replace it:
  - a. For trim with set screw on the handle, loosen the set screw to remove handle.
  - b. For trim without set screw, unscrew the escutcheon until the handle spins freely.