



INSTALLATION GUIDE

Wherever wall controls and diverters

Sept 2013



COMPLETE TRIM



WE-WM-1/2VC



WE-WM-3/4VC



WE-WM-DIV

It is strongly advised to employ a professional plumber when installing this product.

1. The valves may be placed anywhere, depending on the home owner's preference and local plumbing code.
2. Drill 5/8" holes for the valves
(The 2" plated trim rings will cover any gap between the valve stems and the holes)
3. Separate the Valves from the Trim:
 - a. With a #2 Allen wrench, loosen the set screw and remove from the handle.
 - b. With a Phillips-head screwdriver, remove the screw holding the riser to the valve stem.
 - c. Unscrew the escutcheon from the valve stem.
4. Valves should be installed with approximately 2-1/8" of the threading on the stem sleeve exposed from the wall.
5. Install the trim reversing the steps made in step 3. Remember to place the trim ring on the threaded sleeve before the escutcheon. Finish with the handle. Water Test for leaks.