



Oct 2017



COMPLETE TRIM



WE-WM-1/2VC



WE-WM-3/4VC



WE-WM-DIV

It is strongly advised to employ a professional plumber when installing this product.

The valves may be placed anywhere, depending on the home owner's preference and local plumbing code. For all valves, make note of inlets and outlets before plumbing!

1. Separate the Trim from the Valves by unscrewing the escutcheon from the valve stem.
2. Valves should be installed with 2-1/4" of the broached stem exposed from the wall. At least 1/2", and no more than 1-3/4" of the threaded stem should be exposed from wall.
3. Water Test.
4. Install the trim reversing the steps made in step 2. Remember to place the trim ring on the wall before the escutcheon.
5. If the handle doesn't "clock" at the desired position, remove and replace the trim.