



Sonoma Forge fixtures are hand made from mostly brass and copper materials, then plated to achieve the stunning finishes you see in our extensive catalog. Like most outdoor plumbing, these materials don't normally hold up to expanding water in freezing temperatures. This guide will help you winterize your product(s) for freezing conditions. Please contact Sonoma Forge if you have any further questions or concerns.

Wall mounted faucets

Shut off the water supply to the fixture, then turn on all valves to release built-up pressure. It is a good idea to remove the cartridges to help prevent them from cracking, but this is not necessary.

If equipped, the hand shower hose can be unscrewed from the faucet and drained.

Deck mounted faucets

Shut off the water supply to the fixture, then turn on all valves to release built-up pressure. With the valves open, disconnect the supply lines from the angle stops and allow gravity to drain the water. It is a good idea to remove the cartridges to help prevent them from cracking, but this is not necessary.

Deck-mounted fixtures will sometimes hold water in the main body. Using the plastic key provided with your faucet, loosen or remove the aerator to allow the water to escape.

If equipped, the hand shower hose can be unscrewed from the faucet and drained.

Replacement parts

We understand that accidents happen and we are here to help. Please email us if your Sonoma Forge fixture is damaged from freezing temperatures. Detailed photos are very helpful for us to determine what needs to be repaired.